



Astris 7K/8K/10K


Installation Manual
(Hardware)

SIN120070002ATCU0B - Astris 7K/1P2T2

Manual de Instalare
(Hardware)

SIN120080003ATCU0B - Astris 8K/1P2T3

SIN120100003ATCU0B - Astris 10K/1P2T3



318.06.23.0

Before using this product, carefully read all product documentation and retain it for future reference.

Contents

Safety	2
1.1 Personnel Safety	2
1.2 PV Inverter Protection	3
Overview of the Inverter	5
2.1 Functional Models	5
2.2 Network Application	6
2.3 Outline and Dimensions	6
2.4 Working Process	8
2.5 Working Modes	9
Storage	10
Installation	11
4.1 Checking the Outer Packing	11
4.2 Moving the inverter	12
4.3 Identify the PV Inverter	12
4.4 Installation Requirements	13
4.5 Installing a Rear Panel	17
4.6 Installing the inverter	20
Electrical Connections	21
5.1 Connecting Protection Ground (PGND) Cables	21
5.2 Connecting AC Output Cables	23
5.3 Connecting the PV Strings	26
5.4 Connecting Communication Cables	31
5.5 Power limit (optional)	32
5.6 Installation Verification	34
System Operation	35
6.1 Powering ON the Inverter	35
6.2 Powering OFF the Inverter	35
User Interface	36
7.1 HMI specification definition	37

7.2 LCD automatic-page-turning display	38
Maintenance	39
8.1 Routine Maintenance	40
8.2 Inverter Troubleshooting	41
8.3 Removing the Inverter	43
Disposal of the Inverter	44

English

Română

Forward

Thank you for purchasing our products!

Please read this manual before using the product.

This user manual introduces the inverter in terms of its installation, electrical connections, operation, commissioning, maintenance, and troubleshooting. Please read through the manual carefully before installing and using the inverter, and keep the manual well for future reference.

Application Model

Grid-tied PV string inverter

- 7K/8K/10K

Applicable Personnel

This user manual is intended for photovoltaic (PV) inverter operating personnel and qualified electrical technicians.

NOTE!

This user manual is subject to change without prior notice.

Symbol Conventions

Safety symbols used in this manual, which highlight potential safety risks and important safety information, are listed as follows:

Symbol	Description
 DANGER	Indicates an imminently hazardous situation which, if not correctly followed, will result in serious injury or death.
 WARNING	Indicates a potentially hazardous situation which, if not correctly followed, could result in serious injury or death.
 CAUTION	Indicates a potentially hazardous situation which, if not correctly followed, could result in moderate or minor injury.
 NOTICE	Indicates a potentially hazardous situation which, if not correctly followed, could result in equipment failure, or property damage.
 NOTE	Calls attention to important information, best practices and tips: supplement additional safety instructions for your better use of the PV inverter to reduce the waste of your resource.
 REFER	Refer to documentation (Remind operators to refer to the documentation shipped with the inverter).

1 Safety

Before beginning your journey, please read these safety precautions in User Manual carefully.

1.1 Personnel Safety

- a. The PV inverter must be installed, electronically connected, operated and maintained through specially trained technician;
- b. The qualified technician must be familiar with the safety regulations of electrical system working process of PV power generation system, and standards of local power grid;
- c. The technician must read through this User Manual carefully and master it before any operation.

1.2 PV Inverter Protection

NOTE!

As soon as receiving the PV inverter, please check if it is damaged during its transportation. If yes, please contact your dealer immediately.

- a. Do not tamper with any warning signs on the inverter enclosure because these signs contain important information about safe operation.
- b. Do not remove or damage the nameplate on the inverter's enclosure because it contains important product information.

1.3 Installation Safety

NOTE!

Please read the User Manual carefully before installing the PV inverter; warranty or liability will be void from our company if damage is caused by installation faults.

- a. Ensure there is no electronical connections around ports of the PV inverter before installing;
- b. Adequate ventilation must be provided for inverter installation location. Mount the inverter in vertical direction, and ensure that no object is put on the heat sink affecting the cooling. (For details, refer to Chapter 4 Installation).

1.4 Electrical Connections



DANGER

Before installing the inverter, check all electrical ports to ensure no damage and no short circuit. Otherwise personal casualty and/or fire will occur.

- a. Input terminals of the PV inverter apply only to input terminals of PV String; do not connect any other DC source to the input terminals.
- b. Before connecting PV modules, ensure that its voltage is within the safe range; when exposed to any sunlight, PV modules can generate high voltage.
- c. All electrical connections must meet the electrical standards of the country or region.

d. Cables used in electrical connections must be well fixed, good insulation, and with appropriate specification.

1.5 Operating and Commissioning

DANGER

While the inverter operating, high voltage can lead to an electrical shock hazard, and even cause personal casualties. Therefore, operate the PV inverter strictly according to the safety precautions in the user manual.

WARNING

When the photovoltaic array is exposed to light, it supplies a DC voltage to the PCE.

- a. Before getting the permission of electrical power authority in the country/region, the grid-tied PV inverter cannot start generate power.
- b. Follow the procedures of commissioning described in the user manual when commissioning the PV inverter.
- c. Do not touch any other parts'surface except the DC switch when the PV inverter is operating; its partial parts will be extremely hot and can cause burns.

1.6 Maintenance

DANGER

Power OFF all electrical terminals before the inverter maintenance; strictly comply with the safety precautions in this document when operating the inverter.

- a. For personal safety, maintenance personnel must wear appropriate personal protective equipment (like insulation gloves and protective shoes) for the inverter maintenance.

- b. Place temporary warning signs or erect fences to prevent unauthorized access to the maintenance site.
- c. Follow the procedures of maintenance stipulated in the manual strictly.
- d. Check the relevant safety and performance of the inverter; rectify any faults that may compromise the inverter security performance before restarting the inverter.

1.7 Additional Information

NOTE!

To avoid any other unforeseeable risk, contact your dealer immediately, if there is any issue found during operation.

2 Overview of the Inverter

This chapter introduces the inverter and describes its functional model, network application, appearance, dimensions, and working process etc.

2.1 Functional Models

2.1.1 Function

This series is a single-phase grid-tied PV string inverter (transformer less) that converts the DC power generated by PV strings into AC power and feeds the power into power grid.



WARNING

The inverter is transformerless. Add an isolation transformer before grounding the positive/ negative terminal of PV modules (like Thin Film module) for operation.



WARNING

Do not connect PV modules in parallel to several PV inverters for operation.

2.1.2 Model Description

Figure 2.1 shows a model number of the inverter, using 7K/8K and 10K as an example.

Astris 8K

Power class code

Figure 2.1 Model number descriptions

2.2 Network Application

2.2.1 Grid-tied PV Power Systems

The series applies to grid-tied PV power systems for outdoor power stations. Typically, a grid-tied PV power system consists of PV modules, grid-tied inverters, AC distribution units, and low-voltage power grid, as shown in Figure 2.2.




Figure 2.2 a low-voltage grid-tied PV power system

2.3 Outline and Dimensions

2.3.1 Outline

Figures 2.3 to 2.6 show the outline of the inverters as follows:




Figure 2.3 The outline and dimensions of the Inverter



Figure 2.4 The front view and amplification effect of LED indicator area




Figure 2.5 The rear view of this series of inverter

7K/8K/10K

1. DC isolation switch
2. Vent valve
3. PV input connectors
(7K - 2 strings, 8K/10K - 3 strings)
4. COM2(RS-485/meter/CT/DI)
5. COM1(WIFI/GPRS/Ethernet/ RS-485)
6. AC output connector
7. External protection ground interface




Figure 2.6 The bottom view of this series of inverter

2.4 Working Process

2.4.1 Basic principle Description

The 8K-10K inverters are powered by solar panel strings through a DC switch and an overvoltage protection in the following way: 3 panel strings can be connected, the connectors of string 1 and 2 are joined in the same MPPT path, while the 3rd string is connected directly to its own MPPT tracker. In case of the 7KW model, 2 panel strings can be connected, one to each individual MPPT tracker. The 2 independent MPPT paths created inside the inverter will follow the maximum power point of the PV panels. The electrical energy generated from these 2 paths is converted into a direct voltage bus, then the bus is converted by the inverter circuit into alternative current. An EMI filter and a surge protection are used for both the DC and AC conversions to reduce electromagnetic interference.

2.4.2 Circuit Diagrams

Figure 2.7 shows the circuit diagram for the 8-10K PV Inverter




Figure 2.7 circuit diagram

2.5 Working Modes

Three working modes of the inverter are shown as follows: standby, operating, and shutdown.

Table 2.1 shows the conditions for the inverter to switch between working modes.

Modes	Description
Standby	<p>The PV inverter enters the standby mode when</p> <ul style="list-style-type: none">>the input voltage of PV Strings can enable auxiliary power supply to run, but cannot meet the inverter operation requirements.>the input voltage of PV Strings can meet the inverter to-start requirements, but cannot meet its minimum power requirements.
Operating	<p>When the PV inverter is grid-tied and generates electricity, it</p> <ul style="list-style-type: none">> tracks the maximum power point to maximize the PV String output.> converts DC power from PV strings into AC power and feeds the power to the power grid.
Shutdown	<p>The PV inverter switches from standby or operating mode to shutdown mode if detecting a fault or a shutdown command.</p> <p>The inverter switches from shutdown mode to standby mode if receiving a Startup command or detecting that a fault is rectified.</p>

Table 2.1 Working modes description

NOTE!

instructions: if the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

3 Storage

This chapter describes the storage requirements for the inverter.

The following storage instructions apply if the PV inverter will not be deployed immediately:

- > Do not unpack the inverter (put desiccant in the original box if the PV inverter is unpacked).
- > Store the PV inverter at a temperature range of -25°C to +60°C and with the relative humidity of 0% to 100% (no condensing).
- > The PV inverter should be stored in a clean and dry place and be protected from dust and water vapor corrosion.
- > The PV inverter a maximum of six layers of inverters can be stacked.
- > Do not position the inverter at a front tilt, excessive back tilt, or side tilt, or upside down.
- > Conduct periodic inspection during storage. Replace the packing materials immediately if any rodent bites are found.
- > Ensure that qualified personnel inspect and test the inverter before use if it has been stored for a long time.

4 Installation

DANGER


Do not install the inverter on flammable building materials or in an area where flammable or explosive materials are stored.

CAUTION

Do not install the inverter in a place where personnel are likely to come into contact with its enclosure and heat sinks to avoid electrical shock/burn.

4.1 Checking the Outer Packing

- When receiving the inverter, check that the packing materials are intact.
- After unpacking, check that the deliverables are complete, intact, and consistent with your order list.
- Examine the PV inverter and its fittings for damage such as scraps and cracks.



Items	Deliverables
A	The inverter
B	M6 Screw
C	Rear panel
D	File package
E	DC terminal connector group
F	Removal tool for DC connector
G	Expansion screws (reserved for tightening the rear panel)

Figures 4.1 The deliverables: The inverter and its fittings

NOTE!

If any damage mentioned above is found, contact the dealer immediately.

NOTE!

PV modules for non-isolated inverters. Non-isolated inverters shall be provided with installation instructions that require PV modules that have an IEC 61730 Class A rating. If the maximum AC mains operating voltage is higher than the PV array maximum system voltage then the instructions shall require PV modules that have a maximum system voltage rating based upon the AC mains voltage.

4.2 Moving the inverter

After checking the outer packing, move the PV inverter to the designated installation position horizontally. Hold the handles on both sides of the inverter, as shown in **Figure 4.2**.




Figure 4.2 Moving the inverter



CAUTION

- >Do not place the PV inverter with its wiring terminals contacting the floor because the power ports and signal ports at the bottom of the device are not designed to support the weight of the inverter.
- >When placing the inverter on the floor horizontally, put foam or paper under to protect its enclosure.

4.3 Identify the PV Inverter

4.3.1 Nameplate

After moving the PV inverter from packing box, identify it by reading its nameplate labeled on the side of the inverter. The nameplate contains important product information: the model information, communications/technical specifications, and compliance symbols.

4.3.2 Compliance and Safety Symbols

Safety symbol	Description
	Electrical shock! There are residual voltages in the PV inverter. It needs 5 minutes to finish discharge.
	The PV inverter must not be touched when in operation. Its enclosure and heat sinks are extremely hot.
	Electrical shock! This part is charged. Only qualified and/or trained electrical technicians are allowed to perform operations on the inverter.
	If the inverter service life has expired, dispose it in accordance with local rules for disposal of electrical equipment waste. Do not dispose the PV inverter with household garbage.
	The PV inverter is compliant with TUV.

4.4 Installation Requirements

Applies to wall-mounting installation, as described below in detail.


4.4.1 Determining the Installation Position

Basic Requirements

- The inverter is protected to IP65 and can be installed indoors or outdoors.
- The installation method and position must be appropriate for the weight and dimensions of the inverter.
- Do not install the inverter in a place where personnel are likely to come into contact with its enclosure and heat sinks because these parts are extremely hot during operation.
- Do not install the inverter in an area that stores flammable or explosive materials.

Installation Environment Requirements

- The ambient temperature must be below 50°C to ensure the inverter's optimal operation and extend its service life.
- The inverter must be installed in a well ventilated environment to ensure good heat dissipation.
- The inverter must be free from direct exposure to sunlight, rain, and snow to extend its service life. It is recommended that the inverter be installed in a sheltered place. If no shelter is available, build an awning, as shown in **Figure 4.3**.




Figures 4.3 Installation environment with awning (unit: mm)

Carrier Requirements

- The carrier where the inverter is installed must be fire-proof. Do not install the inverter on flammable building materials.
- The wall must be solid enough to bear the weight of the inverter.
- Do not install the inverter on a wall made of gypsum boards or similar materials with weak sound insulation to avoid noise disturbance in a residential area.

Installation Space Requirements

- It is recommended that the inverter be installed at eye level to facilitate operation and maintenance.
- Reserve enough clearance around the inverter to ensure sufficient space for installation and heat dissipation, as shown in **Figure 4.4**.



Figures 4.4 Installation Space Requirements (unit: mm)

- c. When installing multiple inverter, install them along the same line (as shown in **Figure 4.5**) if sufficient space is available, and install them in triangle mode (as shown in **Figure 4.6**) or in stacked mode (as shown in **Figure 4.7**) if no sufficient space is available. The installation modes ensure sufficient space for installation and heat dissipation.




Figure 4.5 Installation along the same line (unit: mm)




Figure 4.6 Installation in triangle mode (unit: mm)





Figure 4.7 Installation in stacked mode (unit: mm)

NOTE!


The clearance between multiple inverters must be increased to ensure proper heat dissipation when they are installed in a hot area.

4.4.2 Installation Mode Requirements

Install the inverter upright or at a maximum back tilt of 15 degrees to facilitate heat dissipation. Some correct / wrong installation modes are shown in **Figures 4.8&4.9** below.



Figures 4.8 The correct installation mode



Figures 4.9 The wrong installation modes

NOTE!

The wrong installation will lead to failure of the inverter operation.

4.5 Installing a Rear Panel

Before installing the inverter, secure the rear panel to a wall.

Step 1 Move out the rear panel from the packing case.

Step 2 Determine the positions for drilling holes (as shown in **Figure 4.10**) using the rear panel.




Figure 4.10 Determine the positions for drilling holes (unit: mm)

Step 3 Level the hole positions using a level gauge, and mark the hole positions using a marker (as shown in Figure 4.11).




Figure 4.11 mark the hole positions using a marker

Step 4 Drill holes using a hammer drill and install expansion bolts, as shown in Figure 4.12.



DANGER

Before drilling the hole on the wall, ensure no damage on the electric wire and/or water pipe inside the wall.

a. Drill a hole in a marked position to a depth of 60 mm using a hammer drill with a $\Phi 10\text{mm}$ bit.

b. Partially tighten an expansion bolt, vertically insert it into the hole, and knock the expansion bolt completely into the hole using a rubber mallet.




Figure 4.12 Punch holes and install expansion (unit: mm)

Step 5 Align the rear panel with the holes, insert expansion bolts into the holes through the real panel, and tighten the expansion bolts to a torque wrench (torque 2-2.5 N·m), as shown in **Figure 4.13**.




Figure 4.13 Installing the real panel

4.6 Installing the inverter

Follow below procedures:

Step 1 Hold the handles at both sides of the inverter and then lift and stand the inverter.

Step 2 Mount the inverter on the rear panel and keep them aligned with each other, as shown in **Figure 4.14**.

Step 3 Tighten the two hexagon screws at the both sides of the inverter to a torque of 3N·m . As shown in **Figure 4.14**.




Figure 4.14 Securing the inverter

5 Electrical Connections

DANGER

Before performing any electrical connections, ensure that both DC and AC Switches are OFF. Otherwise, fatal injury can occur due to the high voltage caused from AC and DC cables.

5.1 Connecting Protection Ground (PGND) Cables

5.1.1 Preparation

The ground cable and OT terminals have been prepared.

- Ground cable: Outdoor copper-core cables with a cross sectional area of 10 mm² or more are recommended.
- Specification of screw:M4;the required torque is 1.2N.m.

OT 6~4

Key parameter

Product series code

Terminal product series code

NOTE!

Good grounding for the inverter helps resist the impact of surge voltage and improve the EMI performance. Connect the PGND cable before connecting the AC power cables, DC power cables, and communication cables.

NOTE!

It is recommended that the ground cable be connected to a nearby ground position. For a system with multiple inverters connected in parallel, connect the ground points of all inverters to ensure equipotential connections.

5.1.2 Wiring Procedures

Step 1 Remove an appropriate length of the insulation layer from the PGND cable using a wire Stripper; the length is a little bit longer than that of OT terminal's crimping end by 2mm~3mm, as shown in **Figure 5.1**.




Figure 5.1 Stripped length (unit: mm)

Step 2 Insert the exposed core wires into the crimping areas of the OT terminal and crimp them using hydraulic pliers, as shown in **Figure 5.2**.




Figure 5.2 Crimping a cable (unit: mm)

Step 3 Remove the ground screws from the ground points, as shown in **Figure 5.3**.




Figure 5.3 Crimping a cable (unit: mm)

Step 4 Secure the PGND cable (done by step 1 & 2) using the ground screw and tighten the screw using a socket wrench (torque 1.2 N·m),as shown in **Figure 5.4**.





Figure 5.4 Secure the PGND cable

5.2 Connecting AC Output Cables

5.2.1 Preparation

The AC power cable and AC terminals have been prepared.

a. AC power cable: Outdoor copper-core cables are recommended. **Table 5.1** describes the specifications.

Cable	Cable type	Cross-sectional Area(mm^2)		Cable Outer Diameter (mm)
		Range	Recommended Value	
AC cable	multi-core outdoor cable	8~14	10	14~20

Table 5.1 AC output cable specifications

b. The recommended specifications of circuit breaker are shown in the table below.

Inverter Model	Recommended Value
7K/8K	50A
10K	60A

Table 5.2 Circuit breaker specifications



WARNING

An independent circuit breaker must be installed on the AC side of each inverter to ensure that the inverter can be safely disconnected from the power grid.



WARNING

Do not connect loads between the AC output terminals of the inverter and circuit breaker.

5.2.2 Procedure of Connecting AC Cables

NOTE!

For your operation and safety sake, please prepare multi-stranded wire, crimping terminals and a proper crimping tool before AC Wiring.

Step 1 Remove an appropriate length of the jacket and insulation layer from the AC output cable.




Figure 5.5 Stripped length (unit:mm)

Step 2 Insert the exposed core wires into the crimp area of the OT terminal and crimp them using hydraulic pliers. Wrap the wire crimp area with heat shrink tubing or PVC insulation tape.




Figure 5.6 Crimping OT terminals

Step 3 Insert the processed AC output cables through waterproof terminals with reserved wire length for electrical connecting.




Figure 5.7 Connecting AC cable

Step 4 RoutAC output cables to L, N and PE on the AC terminal block respectively, and tighten them using screw driver to a torque of 1.5N.m.




Figure 5.8 Connecting AC cable

Step 5 Aligning with the hole position on the AC terminal cover, use a screw driver to tighten screws to a torque of 1.2 N.m.




Figure 5.9 Connecting AC connector

Step 6 Use a torque wrench to tighten the locking cap on the AC cable to a torque of 5N.m.

5.3 Connecting the PV Strings

DANGER

PV Strings connection needs below prerequisites; otherwise, an electrical shock can occur.

PV modules generate electric energy when exposed to sunlight and can create an electrical shock hazard. Therefore, when connecting the PV modules, shield them with opaque cloth.

Before connecting DC input power cables, ensure that the voltage on the DC side is within the safe range and that the DC SWITCH on the inverter is OFF. Otherwise, high voltage may result in electric shock.

When the inverter is grid-tied, it is not allowed to maintain DC input power cables, such as connect or disconnect a string or a module in a string. Only after the inverter enters in shutdown mode, it is allowable for preceding DC input power cables maintenance.

English

Română



WARNING

Grounding of the PV Strings requires the following prerequisites; otherwise, a fire can occur.

PV modules connected in series in each PV string must be of the same specifications.

The maximum open-circuit voltage of each PV string must be always lower than or equal to its permitted range.

The maximum short circuit current of each PV string must be always lower than or equal to its permitted range.

The positive and negative terminals of PV modules must be connected to the positive and negative DC input terminals of the inverter respectively. negative DC input terminals of the inverter respectively.

During the installation of PV strings and the inverter, the positive or negative terminals of PV strings cannot be connected with short circuit.

5.3.1 Preparation

Route collecting for the installation of PV strings and inverter:

PV Strings	Number of input Route
1	Connected to any route
2	Connected to route 1 &3
3	Connected to route 1,2 & 3

PV Strings DC input cable and connectors have been prepared; Table 5.3 lists the recommended outdoor copper-core DC input cable specifications.

Cable	Cable type	Cross-sectional Area(mm^2)		Cable Outer Diameter (mm)
		Range	Recommended Value	Range
DC cable	common PV cables in the industry (model: PV1-F)	4~6	4	5~8

Table 5.3 Recommended DC input cable recommended specifications

Connectors of PV Strings: Positive and negative DC input connectors are used, as shown in **Figure 5.10** and **Figure 5.11**.




Figure 5.10 Positive connector compositions




Figure 5.11 Negative connector compositions

NOTE!

Positive and negative metal connectors are packed with positive and negative connectors respectively when shipped out. After unpacking, keep the positive and negative ones separate to avoid confusion.

Procedures of connecting the PV Strings

Step 1 Remove an appropriate length of the insulation layer from the positive and negative power cables using a wire stripper, as shown in below Figure.




Figure 5.12 Removing insulation layer for DC cable (unit: mm)

Step 2 Insert the exposed areas of the positive and negative power cables into the metal terminals of the positive and negative connectors respectively and crimp them using a crimping tool, as shown in **Figure 5.11**.




Figure 5.13 Crimping a metal connector

Step 3 Insert the crimped positive and negative power cables into the corresponding positive and negative connectors until a “click” sound is heard, as shown in **Figure 5.12**.




Figure 5.14 Connecting positive and negative connectors

Step 4 Tighten the locking nuts on the positive and negative connectors using a removal wrench, as shown in **Figure 5.13**.




Figure 5.15 Locking connectors

Step 5 Measure the voltage of every route Strings using a multimeter. Ensure that the polarities of the DC input power cables are correct, as shown in **Figure 5.16**.




Figure 5.16 Checking the voltage of every route Strings

Step 6 Insert the positive and negative connectors into their corresponding terminals of the inverter until a “click” sound is heard, as shown in **Figure 5.17**.




Figure 5.17 Connecting to the inverter

Step 7 After connecting the PV strings, ensure that all connectors are in position by checking for resistance when a slight pull is applied.

5.4 Connecting Communication Cables

5.4.1 Communication Mode Description

You can use the following communication modes to implement communication: Bluetooth, WIFI, GPRS and RS485 all of which are described as follows.

Bluetooth Module

You can turn on the Bluetooth function of the mobile phone, and set parameters and monitor data of the inverter through the mobile APP. For details about operation, refer to APP User Manual.

WIFI & GPRS & RS485 Modules

Following figure show inverter's interface to connect WIFI, GPRS and RS485 accessory, please refer user manual of accessory for connecting method and its setting.

Module	Function description
WIFI	WIFI module implements communication with Cloud server through wireless network to monitor PV inverter's data status. For more details, refer to WIFI Product Application Manual.
GPRS	GPRS module communicates with Cloud server through a mobile phone to monitor PV inverter's data status. For more details, refer to GPRS Product Application Manual.
RS485	RS485 switching module monitors PV inverter's data status through collecting and uploading data to Cloud server. For more details, refer to RS485 switching Product Application Manual.
NOTE	You can choose and buy WIFI/GPRS/RS485 communication modules from the company. The baud rate supported by RS485: 9600BPS

Table 5.4 WIFI & GPRS & RS485 Modules Description




Figure 5.18 Wiring diagram of Inverter+CT

< Power Limit	
Power limit function	Power limit function
Disable	<input checked="" type="checkbox"/> CT sensor
Power limit mode	Power limit mode
Meter on Grid	On Grid
Power limit CT ratio	Power limit CT ratio
1000:1	1000:1
Maximum feed in grid power(W)	Maximum feed in grid power(W)
0	0
Digital Power Meter Type	Digital Power Meter Type
Unknown	Unknown

Figure 5.19 Settings via APP

- Power limit function set to “CT sensor”
- Set the CT position base on the meter installed on load or on grid
- Set maximum feed-in grid power if needed
- Set Power limit CT ratio

5.5.2 Wiring diagram of Inverter+Meter




Figure 5.20 Wiring diagram of Inverter+Meter

Power Limit	
Power limit function	Power limit function
Disable	Digital Power Meter
Power limit mode	Power limit mode
Meter on Grid	On Grid
Power limit CT ratio	Power limit CT ratio
1000:1	1000:1
Maximum feed in grid power(W)	Maximum feed in grid power(W)
0	0
Digital Power Meter Type	Digital Power Meter Type
Unknown	DDSU666

Figure 5.21 Settings via APP

- Set the “Power limit function” to “Digital Power Meter”
- Set the Digital Power Meter Type
- Set the meter position base on the meter installed on load or on grid
- Set maximum feed-in grid power if needed
- Set “Power limit CT ratio” only when using inverter+CT

When “Power limit function” is set to “Digital Power Meter”, the RS485 of inverter will change to a Host that will communicate with digital meter using Modbus-RTU protocol (9600 BPS, 8 data bit, 1 stop bit, no parity data format) through communication address 1. Please make sure that the meter is set to Modbus-RTU, 9600, 8-N-1 with address 1. For details of digital meter setting operation, please refer to the meter user manual.

5.6 Installation Verification

Check the following items after the inverter is installed according to **Table 5.5**.

1. No other objects are put on the PV inverter.
2. All screws, especially the screws used for electrical connections, are tightened
3. The PV inverter is installed correctly and securely.
4. Ground, AC, DC, and Communications cables are connected tightly/ correctly and securely.
5. Check and ensure there is no open circuit or short-circuits at AC and DC terminals using multimeter.
6. Waterproof connectors at AC terminals and RS485 ports are plugged with waterproof plugs tightly.
7. Covers at AC terminals are tightened.
8. Idle terminals are sealed.
9. All safety warning symbols are intact and complete on the inverter.

Table 5.5 Self-check items after installation

6 System Operation

6.1 Powering ON the Inverter

Step 1: Switch ON the AC circuit breaker.

Step 2: If the inverter has a switch, turn the switch to “ON” state.

Step 3: Observe statuses of LED indicator lights on the inverter according to Table 7.1.

NOTE!

When LED status lights display the inverter has entered grid-connecting, it means the inverter is operating well. Any query during operating the PV inverter, call your dealer.

6.2 Powering OFF the Inverter

Step 1: Run a shutdown command on the mobile APP.

Step 2: Switch off the circuit breaker at AC terminal.

Step 3: If the inverter has a switch, turn the switch to “OFF” to observe.




WARNING

After the inverter is power off, the remaining electricity and heat may still cause electrical shock and body burns. Maintenance of the inverter shall begin ten minutes after the power-off.

7 User Interface

Display screen of inverter is composed of LED indicator (LCD is optional for some models). LED contains three color states, blue, green and red respectively. For more details, refer to **Table 7.1 HMI specification definition.**



NOTE!

You can view & set data of the inverter through inverter APP. For details about operation, refer to APP User Manual. APP User Manual is available for free from website www.nJoy.global

English

Română

7.1 HMI specification definition

LED Indicator	Description	Status
Blue led	Standby	blink(slowly)
	Normal status	on
Green led	Limited power operation	on
Red led	Refer to the table below	
Warning Definition	LCD Display	Status
Grid over voltage	A0 Grid OV	Red led blink(slowly)
Grid under voltage	A1 Grid UV	Red led blink(slowly)
Grid absent	A2 Grid Loss	Red led blink(slowly)
Grid over frequency	A3 Grid OF	Red led blink(slowly)
Grid under frequency	A4 Grid UF	Red led blink(slowly)
PV over voltage	B0 PV OV	Red led blink(quickly)
Insulation resistance abnormal	B1 Imp abn	Red led blink(quickly)
Leakage current abnormal	B2 Lkge abn	Red led blink(quickly)
Control power abnormal	C0 Powerfail	Red led on
Arc fault	C1 Arc fault	Red led on
Dc bias current abnormal	C2 OP Dc OC	Red led on
Inverter relay abnormal	C3 RLY abn	Red led on
Inverter over temperature	C5 SYS OT	Red led on
Leakage current HCT abnormal	C6 LkgCT abn	Red led on
System fault	C7 SYS err	Red led on

Fan fault	C8 FAN lock	
DC link under voltage	C9 Bus UV	Red led on
DC link over voltage	CA Bus OV	Red led on
Internal Communications fault	CB COM err	Red led on
Software version incompatibility	CC FW Incomp	Red led on
EEPROM fault	CD EEP err	Red led on
Sampling inconsistency	CE Inconsis	Red led on
Boost circuit abnormal	CG Bst abn	Red led on
Remote off	CN RMT OFF	

Table 7.1 HMI specification definition

7.2 LCD automatic-page-turning display

Mode	Display content	Note
The LCD display interface of the inverter standby state is shown in the following sequence:	Astris 8k Ver 01.00.00	Model name Version
	Udc 360/360V Vac 220V	PV voltage AC voltage
	Today 80kWh Etot 8000kWh	Today Energy Total Energy
	A0 Grid OV B1 Imp abn	Warning

The LCD display interface for countdown of inverter gridconnected is shown in the right picture:		Start counter down
The LCD display interface of the inverter grid-connected state is shown in the figure on the right:		Output power Today Energy
		Total Energy Total Hours
		PV voltage PV current
		AC voltage AC current
		hour:minute year/month/day

Table 7.2 LCD automatic-page-turning display

8 Maintenance



WARNING

Before maintaining and commissioning inverter and its peripheral distribution unit, switch off all the charged terminals of the inverter and wait at least 10 minutes after the inverter is powered off.

8.1 Routine Maintenance

Check Item	Check Content	Maintain content	Maintenance Interval
inverter output status	Statistically maintain the status of electrical yield, and remotely monitor its abnormal status.	NA	Weekly
PV inverter cleaning	Check periodically and ensure that the heat sink is free from dust and blockage.	Clean periodically the heat sink.	yearly
PV inverter running status	Check that the inverter is not damaged or deformed. Check for normal sound emitted during inverter operation. Check and ensure that all inverter communications is running well.	If there is any abnormal phenomenon, replace the relevant parts.	monthly
PV inverter Electrical Connections	Check and ensure that AC, DC, and communication cables are securely connected; Check and ensure that PGND cables are securely connected; Check and ensure that cables are intact and there is no wire aging	If there is any abnormal phenomenon, replace the cable or re-connect it.	Semiannually

Table 8.1 Maintenance checklist and interval

8.2 Inverter Troubleshooting

When the inverter has an exception, its basic common warning and exception handling methods are shown in the table 8.2.

Alarm Name	Causes	Measures Recommended
Grid Over Voltage	The grid voltage exceeds its allowable range.	<ol style="list-style-type: none">If the alarm occurs accidentally, the power grid may be abnormal accidentally. No extra action is needed.
Grid Under Voltage		<ol style="list-style-type: none">If the alarm occurs repeatedly, contact the local power station. After receiving approval of the local power bureau, revise the electrical protection parameters setting on the inverter through mobile APP.
Over Frequency		<ol style="list-style-type: none">If the alarm persists for a long time, check whether the AC circuit breaker/AC terminals is disconnected or not, or if the grid has a power outage.
Under Frequency		
PV Over Voltage	PV modules input voltage exceeds the inverter's allowable range.	Check the number of PV modules and adjust it if need.
PV Under Voltage	PV modules input voltage is under the inverter's defaulted protection value.	<ol style="list-style-type: none">When sunlight intensity weakens, PV modules voltage decreases. No action is needed.If such phenomena occur when sunlight intensity does not weaken, check if there is short circuit, open circuit etc. in the PV strings.
Insulation Resistance Abnormal	A short circuit exists between PV strings and protection ground. PV strings are installed in a long-term moist environment.	<ol style="list-style-type: none">Check the insulation resistance against the ground for the PV strings. If a short circuit has occurred, rectify the fault.If the insulation resistance against the ground is less than the default value in a rainy environment, set Insulation resistance protection on APP.

Residual Current Abnormal	The insulation resistance against the ground at the input side decreases during the inverter operation, which causes excessively high residual current.	1. If the alarm occurs accidentally, possibly the external circuits are abnormal accidentally. The inverter automatically recovers to the normal operating status after the fault is rectified. 2. If the alarm occurs repeatedly or lasts a long time, check whether the insulation resistance against the ground of PC strings is too low.
PV Strings Abnormal	PV strings have been obscured for a long time. PV strings are ageing or deteriorated.	1. Check whether the PV string is obscured. 2. If the PV string is clean and not obscured, check whether the PV modules are aging or deteriorated.
PV Strings Reverse	The cables of PV strings are connected reversely during the inverter installation.	Check whether the cables of PV strings are correctly connected. If they are connected reversely, reconnect the cables.
BUS Under Voltage	Abnormal internal energy control imbalance has been triggered by the PV Strings/grid sharp change of working conditions	1. If the alarm occurs occasionally, the inverter can automatically recover to the normal operating status after the fault is rectified.
BUS Over Voltage		2. If the alarm occurs repeatedly, contact your dealer for technical support.
Invert Module Fault		
BOOST Fault		
EEPROM Fault	EEPROM Component damaged	Replace the monitoring board.
Zero power generation and Yellow alarm light illuminating in remote monitor system	Communications outage	If modem or other data logger is used, please reboot it; if still does not work after rebooting, contact your dealer.

remote monitor displays zero power generation	Communications outage	If modem or other data logger is used, please reboot it; if still does not work after rebooting, contact your dealer.
remote monitor displays no output voltage	Output switch tripping	Check if DC switch is damaged, and if not, switch it to ON. If it still doesn't work, contact your dealer.
Inverter off grid	1. Power grid fault; 2. DC switch tripping	1. Wait till power is restored; 2. Turn DC switch to ON, and if DC switch trips a lot, contact your dealer.
Arc fault detection	Electrical Arcs	a. Check whether the circuit of the solar module is abnormal, including wire integrity, joint tightness. b. After the faults removal, turn off the AC/DC switch and start the inverter again, or click AFD Reset function on the APP page to eliminate the alarm.

Table 8.2 Common troubleshooting measures

NOTE!

If you cannot clear the preceding alarm according the measures recommended, contact your dealer in a timely manner.

8.3 Removing the Inverter

Perform the following procedures to remove the inverter:

Step 1: Disconnect all cables from the inverter, including communications cables, DC input power cables, AC output power cables, and PGND cables.

NOTE!

When removing DC input connector, insert the removal wrench to the bayonet, press the wrench down, and take out the connector carefully.

Step 2: Remove the inverter from the rear panel.

Step 3: Remove the rear panel.



WARNING

Before removing DC input connector, double check and ensure DC input switch is turned OFF to avoid inverter damage and personal injury.

9 Disposal of the Inverter

The PV inverter and its packing case are made from environment-friendly materials. If the inverter service life has expired, do NOT discard it with household garbage; dispose the inverter in accordance with local environmental laws and regulations.



Disposal of Old Electrical & Electronic Equipment

(Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste.

Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The recycling of materials will help to conserve natural resources.

Cuprins

Masuri de siguranta	48
1.1 Masuri de precautie pentru personalul autorizat	48
1.2 Masuri de precautie in operarea invertorului fotovoltaic	49
1.3 Precautii de instalare	49
1.4 Conexiunea electrica	49
1.5 Operare si punere in functiune	50
1.6 Mantenanta	50
1.7 Informatii aditionale	51
Prezentarea invertorului	51
2.1 Model de functionare	51
2.2 Aplicatii	52
2.3 Dimensiuni si prezentare	53
2.4 Functionarea invertorului	54
2.5 Stari de functionare	55
Depozitare	56
Instalarea	57
4.1 Verificarea ambalajului	57
4.2 Manipularea invertorului	58
4.3 Identificarea tipului de invertor	58
4.4 Criterii de instalare	59
4.5 Instalarea panoului din spate	63
4.6 Instalarea invertorului propriu-zis	66
Conexiunile electrice	67
5.1 Conectarea cablului de protectie impamantare (PGND)	67
5.2 Conectarea cablului de iesire curent alternativ (AC)	69
5.3 Conectarea panourilor fotovoltaice	72
5.4 Conectarea cablurilor de comunicatie	77
5.5 Limitator de putere senzor	78
Operarea sistemului	81
6.1 Pornirea invertorului	81

6.2 Oprirea invertorului	81
Interfata utilizatorului	82
7.1 Definirea informatiilor starilor HMI	83
7.2 Rasfoirea automata si semnificatia simbolurilor afisate	84
Mantenanta	85
8.1 Mantenanta periodica	86
8.2 Depanare invertor	87
8.3 Dezinstalarea invertorului	90
Colectarea invertorului pentru reciclare	90

English

Română

Mulțumim pentru că ați ales produsele noastre!

Acest manual prezinta invertorul din punct de vedere al montarii, instalarii si conectarii electrice, functionarii, punerii in functiune, mentenantei si a depanarii. Va rugam sa parcurgeti manualul inainte de a instala si opera invertorul si pastrati-l pentru viitoare referinte.

MODEL

Invertor fotovoltaic on-grid

- 7K/8K/10K

Pentru personal autorizat

Acest manual de utilizare este dedicat pentru personal autorizat in instalari de inverteoare on-grid si pentru electricieni calificati.

NOTIFICARE!

Acest manual de utilizare este supus modificărilor specifice fără o notificare prealabilă.

Simboluri de siguranta

Simbolurile utilizate in acest manual evidențiaza riscurile potențiale si informatiile care asigura siguranta operatorului, si sunt prezentate dupa cum urmeaza:

Simbol	Descriere
	Indica situatii periculoase iminente care incorrect executate pot duce la raniri grave sau chiar la deces.
	Indica situatii potential periculoase care incorrect executate pot duce la raniri grave sau chiar la deces.
	Indica situatii potential periculoase care incorrect executate pot rezulta in raniri usoare si moderate.
	Indica situatii potential periculoase care incorrect executate pot duce la daune asupra echipamentului sau a proprietati.
	Atrage atenția asupra informațiilor importante, a celor mai bune practici și sfaturi: completari a instructiunilor suplimentare de siguranță pentru o mai bună utilizare a invertorului fotovoltaic și pentru a reduce risipa de resurse.
	Indica o referinta catre documentatia livrata cu echipamentul.

1 Masuri de siguranta

Inainte de a opera produsul, va rugam sa cititi cu atentie masurile de precautie prezentate in acest manual.

1.1 Masuri de precautie pentru personalul autorizat

- Invertorul trebuie instalat, conectat, operat si verificat doar de tehnicieni / electricieni specializati.
- Tehnicianul specializat trebuie sa cunoasca reglementarile si masurile de siguranta in ceea ce priveste reteaua electrica, functionarea invertorului on grid si standardele electrice locale.
- Tehnicianul specializat trebuie sa se familiarizeze cu informatiile prezentate in acest manual inainte de operarea invertorului.

1.2 Masuri de precautie in operarea invertorului fotovoltaic

NOTIFICARE!

Imediat dupa primirea invertorului verificati daca s-au produs daune in timpul transportului. Daca exista, contactati imediat unitatea de unde s-a achizitionat echipamentul.

- a. Nu ignorati avertismentele prezente pe carcasa invertorului deoarece ele contin informatii importante despre operarea lui in siguranta.
- b. Nu indepartati sau deteriorati informatiile de identificare ale invertorului deoarece contin informatii importante despre produs.

1.3 Precautii de instalare

NOTIFICARE!

Va rugam sa parcurgeti cu atentie manualul de utilizare inainte de a instala invertorul fotovoltaic; compania producatoare nu va fi raspunzatoare si nu va acorda garantie unui echipament deteriorat in timpul instalarii.

- a. Asigurati-vă ca nu există interferențe electronice în jurul invertorului înainte de instalare.
- b. Un spațiu de ventilație adecvat trebuie avut în vedere la momentul instalării. Montarea invertorului trebuie să se facă în poziție verticală și asigurati-vă că niciun obiect nu obstruează radiatorul, și implicit racirea corespunzătoare. (Pentru detalii consultați Capitolul 4).

1.4 Conexiunea electrică



PERICOL

Inaintea instalarii invertorului, verificati sa nu existe deteriorari sau scurtcircuit la porturile electrice. In caz contrar exista riscul de vata mari corporale sau de incendiu.

- a. Terminalele de intrare ale invertorului se potrivesc doar cu conectorii panourilor fotovoltaice; nu conectati alta sursa de curent continuu (DC) la intrarea invertorului.
- b. Înainte de conectarea panourilor la invertor, asigurati-vă că tensiunea este în limita de siguranță; expuse la soare panourile vor genera tensiuni mari.
- c. Toate conexiunile electrice trebuie facute după standardele în vigoare din țara sau regiunea respectiva.

- d. Cablurile utilizate la conexiuni trebuie bine fixate, bine izolate si cu specificatiile corecte.

1.5 Operare si punere in functiune

PERICOL

In timpul in care invertorul functioneaza se vor genera tensiuni mari care pot fi periculoase si cauza electrocutari. Va sfatuim sa urmati cu strictete masurile de precautie prezentate in acest manual.

AVERTISMENT

In momentul in care sistemul fotovoltaic este expus luminii va genera curent continuu (DC).

- Invertorul fotovoltaic on-grid nu poate fi pus in functiune cu scopul de a genera electricitate inainte de a obtine toate aprobarile autoritarilor locale din tara sau regiunea in care se executa instalarea.
- Urmati procedura de punere in functiune a invertorului, asa cum este descrisa in manualul de utilizare.
- Nu atingeti nicio suprafaata a invertorului atat timp cand functioneaza, cu exceptia switch-ului DC. Suprafetele invertorului se pot incalzi foarte mult si pot cauza arsuri.

1.6 Mantenanta

PERICOL

Opriti toate terminalele electrice inainte de a executa mentenanta invertorului; urmati cu strictete masurile de siguranta in timpul operarii invertorului.

- Pentru o protectie eficienta a personalului autorizat de mentenanta, este necesar echipament de protectie compus din manusi izolatoare si ghete de protectie.

- b. In timpul mentenantei instalati temporar un perimetru de siguranta impotriva accesului neautorizat compus din semne distincte si garduri de protectie.
- c. Urmati cu strictete procedura de mentenanta prezentata in acest manual.
- d. Verificati toti parametrii de performanta si siguranta; corectati eventualele erori care poate impiedica functionarea eficienta si performanta a invertorului inainte de a-l reporni.

1.7 Informatii aditionale

NOTIFICARE!

Daca se identifica orice defect sau imperfektiiune in functionare, va rugam sa contactati unitatea de unde ati achizitionat invertorul pentru a preveni orice risc viitor.

2 Prezentarea invertorului

Acest capitol prezinta caracteristicile invertorului, functionarea lui, aplicatia aferenta, dimensiuni, aspect etc.

2.1 Model de functionare

2.1.1 Tip invertor

Acest invertor este de tip on-grid, monofazat, fara transformator care prelucraza curentul continuu (DC) generat de panourile fotovoltaice in curent alternativ (AC) catre aplicatiile conectate si catre reteaua electrica, in caz de surplus.



AVERTISMENT

Acest invertor nu are transformator. Adaugati un circuit de izolare inainte de a impamanta terminalele pozitive si negative ale panourilor fotovoltaice.



AVERTISMENT

Nu conectati panourile fotovoltaice in paralel la multiple invertoare.

2.1.2 Denumirea modelului de invertor

Figure 2.1 Schema de mai jos reprezinta felul in care este denumit modelul de invertor, utilizand 8K ca exemplu




Figure 2.1 Denumirea modelului

2.2 Aplicatii

2.2.1 Invertor fotovoltaic on grid

Aceasta documentatie se refera la invertoarele fotovoltaice care se conecteaza la reteaua electrica publica. De obicei, aceste invertoare on-grid sunt formate din: Panouri solare, Invertor fotovoltaic on-grid, Unitatea de distribuire a curentului electric AC, Retea de electricitate de joasa tensiune




Figure 2.2 Invertor on-grid conectat la reteaua de joasa tensiune

2.3 Dimensiuni si prezentare

2.3.1 Schita

Figurile de mai jos prezinta schita invertorului.




Figura 2.3 Prezentarea invertorului 7K/8K/10K




Figura 2.4 Vedere din fata cu zona LED




Figura 2.5 Vedere din spate

7K/8K/10K

1. Circuit de iolare DC
2. Valva de ventilatie
3. Conectori intrare panouri fotovoltaice (7K - 2 siruri, 8K/10K - 3 siruri)
4. COM2(RS-485/meter/CT/DI)
5. COM1(WIFI/GPRS/Ethernet/ RS-485)
6. Conector iesire AC
7. External protection ground interface




Figura 2.6Vedere de jos

2.4 Functionarea invertorului

2.4.1 Principiul de functionare

Invertoarele 7K/8K/10K sunt alimentate de sirurile de panouri solare prin intrerupatorul DC si protectia la supratensiune in modul urmator: se pot conecta 3 siruri de panouri, conectorii sirurilor 1 si 2 unindu-se intr-o ruta comuna MPPT, iar sirul trei este conectat direct la prorpiul sau tracker MPPT. La invertorul de 7K se conecteaza 2 siruri de PV, fiecare la cate o ruta MPPT. Cele 2 cai MPPT, independente una fata de cealalta, situate in interiorul invertorului vor urmari punctul puterii maxime a panourilor PV. Energia electrica de pe aceste 2 cai e convertita in magistrala de tensiune continua, apoi aceasta este convertita in curent alternativ de catre circuitul invertor. Un filtru EMI si o protectie la supratensiuni sunt folosite atat pe partea de curent continuu cat si pe partea de curent alternativ pt. a reduce interferenta electromagneticica.

2.4.2 Schema circuit

Mai jos, este prezentata schema circuitului pentru invertorul de putere 8-10K




Figura 2.7 Diagrama

2.5 Stari de functionare

Starile de functionare ale invertorului sunt: Stand-by (repaus), Pornit și Oprit. Tabelul de mai jos prezintă condițiile în care invertorul poate fi într-o stare din starile specificate.

Stare	Descrierea starilor de functionare
Stand-by/ Repaus	Invertorul este în repaus atunci când: > Tensiunea de intrare de la panourile fotovoltaice poate porni o sursă de putere auxiliară, dar nu poate atinge parametrul minim de funcționare al invertorului. > Tensiunea de intrare de la panourile fotovoltaice atinge parametrul minim de funcționare pentru a-l porni, dar nu poate menține funcționarea lui.
Pornit / În funcțiune	Atunci când invertorul este on-grid și generează electricitate, el poate: >ține cont de punctul maxim de putere consumat pentru a maximiza performanța sirului de panouri fotovoltaice. >face conversia de la curent continuu (DC) la curent alternativ (AC) pentru a-l injecta în rețea electrică.
Oprit	Invertorul va comuta în stare Oprit dacă detectează o eroare sau o comandă de închidere. Invertorul își schimbă starea din Oprit în Stand-by dacă primește o comandă de Pornire sau detectează că o eroare a fost remediată.

NOTIFICARE!

Instructiune: Daca echipamentul este folosit in mod diferit de cel specificat de producator, protectiile prevazute nu vor functiona eficient.

3 Depozitare

Acest capitol descrie conditiile pentru depozitarea invertorului.

Aceste instructiuni trebuie respectate in cazul in care invertorul nu este instalat imediat.

- > Nu desfaceti ambalajul original al invertorului (daca se desface cutia, puneti un pachet cu agent anti-umiditate in cutia originala a invertorului).
- > Depozitatii invertorul la temperaturi intre -25 grade Celsius si +60 grade Celsius cu umiditatea relativa de la 0-100%, fara condens.
- > Invertorul trebuie depozitat in spatii curate si uscate pentru a fi protejat de praf si vaporii de apa.
- > Se pot depozita maxim 6 straturi de invertoare, unul peste celalalt.
- > Nu pozitionati invertorul in plan inclinat, pe o parte sau invers.
- > Inspectati periodic invertorul in timpul depozitarii. Inlocuiti imediat ambalajul daca se gasesc urme de rozatoare.
- > Asigurati-v-a ca invertorul este testat de personal autorizat inainte de instalare, dupa o perioada lunga de depozitare.

4 Instalarea

⚠ PERICOL


Nu instalati invertorul aproape de materiale inflamabile (inclusiv materiale de constructii folosite) sau explozibile.

⚠ ATENTIIONARE

Nu instalati invertorul intr-un loc usor accesibil de catre personal neautorizat care poate veni in contact cu oricare parte a carcasei sau radiator si pot suferi arsuri sau electrocutari.

4.1 Verificarea ambalajului

- a. La primirea invertorului, verificati ca ambalajul sa fie intact.
- b. Dupa inlaturarea ambalajului, verificati ca toate componentele sa fie in intacte si complete, in concordanță cu lista din comanda.
- c. Examinati invertorul sa nu aiba facute reparatii ale crapaturilor si zgarieturilor.



Notatie	Livrabil
A	Invertorul
B	Suruburi M6
C	Suportul de perete
D	Listă componentelor
E	Grup de conectori terminal DC
F	Unealta pentru indepartarea conectorului DC
G	Dibluri / suruburi (pentru atasarea suportului si a panoului din spate)

Figura 4.1 Livrabile: Invertorul si accesoriile

NOTIFICARE!

Daca se identifica orice defect va rugam sa contactati Unitatea de unde ati achizitionat echipamentul.

NOTIFICARE!

Panouri fotovoltaice pentru invertoare non-isolated. Acest tip de invertor este insotit de instructiuni de instalare ce specifica ca si cerinte panouri fotovoltaice care sunt certificate IEC 61730, rating Clasa A. Daca tensiunea maxima a retelei AC e superioara tensiunii maxime a matricii de panouri voltaice, se recomanda folosirea de module PV care sunt certificate pentru o tensiune maxima corelata cu tensiunea retelei AC

4.2 Manipularea invertorului

Dupa ce ati verificat ambalajul exterior, mutati invertorul in zona in care se doreste instalarea, in pozitie orizontala (cu fata in sus). Manipulati invertorul cu ajutorul celor 2 manere de pe lateralul carcasei. Ca in figura de mai jos




Figura 4.2 The deliverables: The inverter and its fittings



ATENTIONARE

Nu asezati invertorul pe terminalele de conectare deoarece porturile de pe partea inferioara nu rezista la greutatea acestuia. Cand asezati invertorul in pozitie orizontala, cu fata in sus, asezati-l pe o bucată de polistiren expandat sau carton pentru a-i proteja carcasa.

4.3 Identificarea tipului de invertor

4.3.1 Cod de identificare

Dupa mutarea invertorului din cutie, identificati tipul de invertor dupa numarul de pe eticheta laterala. Acea eticheta trebuie sa contine informatii importante despre produs: model, specificatii tehnice, simbolurile de conformitate.

4.3.2 Simboluri de conformitate

SIMBOL	DESCRIERE
	Pericol de electrocutare! Există tensiune reziduală în invertor. Are nevoie de 5 minute pentru descarcarea completă.
	Invertorul nu trebuie atins în funcționare. Carcasa și radiatorul sunt extrem de fierbinti.
	Pericol de electrocutare! Pericol de descarcare electrică Acces strict pentru personal autorizat!
	Când durata de viață a invertorului a expirat, respecta reglementările locale în vigoare pentru reziduurile de acest tip. Nu aruncați invertorul împreună cu reziduurile menajere.
	Acest invertor este în conformitate cu reglementările TUV.

4.4 Criterii de instalare

Aplicabile pentru montarea pe perete, aşa cum este descris în detaliu, mai jos.

4.4.1 Stabilirea pozitiei de instalare

Criterii de baza

- a. Invertorul are protecție IP65 și poate fi instalat în interior sau exterior.
- b. Metoda de instalare și poziția este determinată în funcție de greutatea și dimensiunile invertorului.
- c. Nu instalați invertorul într-un loc usor accesibil de personal neautorizat care poate veni în contact cu oricare parte a carcasei sau radiator și pot suferi arsuri sau electrocutări.
- d. Nu instalați invertorul în zone cu risc de incendiu sau materiale inflamabile.

Criterii pentru mediu de instalare

- a. Temperatura ambientala trebuie mentinuta sub 50°C pentru o functionare corecta si o durata de viata mai mare.
- b. Invertorul trebuie instalat intr-un spatiu foarte bine ventilat pentru a asigura disiparea eficienta a caldurii.
- c. Invertorul nu trebuie expus direct la razele soarelui, ploaie, ninsoare pentru a-i extinde perioada de viata. Este recomandat sa fie instalat in interior. Daca nu este posibila instalarea in interior este recomandata achizitionarea unei copertine sau acoperament, cum sugereaza schita de mai jos.




Figura 4.3 The deliverables: The inverter and its fittings

Criterii pentru peretele de instalare

- a. Adapostul unde se va efectua instalarea invertorului trebuie sa fie rezistent la foc. Nu instalati invertorul aproape de materiale inflamabile.
- b. Peretele pe care se va efectua instalarea trebuie sa sustina greutatea invertorului.
- c. Nu instalati invertorul pe pereti falsi, placi de gips-carton sau pereti slab izolati fonic pentru a evita zgomotele puternice produse in timpul functionarii.

Criterii pentru adapost

- a. Este recomandata instalarea la nivelul ochilor pentru a facilita operarea si mentenanta.
- b. Asigurati un spatiu suficient pentru a disipa caldura emisa si pentru a se asigura o instalare corecta, cum se arata in figura urmatoare.




Figura 4.4 Spatiul necesar pentru instalare.

c. La instalarea invertoarelor multiple, instalati-le pe aceeasi linie, daca exista suficient spatiu la dispozitie. In caz contrar, instalati-le sub forma unui triunghi echilatera ca in figura 4.6 sau unul sub celalalt cu arata figura 4.7




Figura 4.5 Instalarea in linie a mai multor invertoare




Figura 4.6 Instalarea invertoarelor in metoda triunghiului




Figura 4.7 Instalarea Invertoarelor in modul cladit

NOTIFICARE!

Cu cat e mai mare temperatura ambientala a mediului de instalare cu atat trebuie pastrata o distanta mai mare intre inverteoare.

4.4.2 Criterii pentru pozitia de instalare

Instalarea invertorului se face in pozitie verticala la un unghi de inclinare maxim de 15 grade pentru o disipare a caldurii eficienta. Exemple de instalare corecta si gresita in schita urmatoare.




Figura 4.8 Modul de instalarea corect.




Figura 4.9 Modul de instalare incorrect.

NOTIFICARE!

Instalarea invertorului in pozitie gresita va duce la defectarea sa.

4.5 Instalarea panoului din spate

Inainte de instalarea efectiva a invertorului se va instala panoul / suportul din spate.

Pasul 1. Scoateti panoul din spate din ambalaj.

Pasul 2. Masurati unde se vor executa orificiile de fixare utilizand acest panou, cum e prezentat in schita de mai jos.





Figura 4.10 Determinarea orificiilor de fixare

Pasul 3. Poziționați orificiile corect cu ajutorul unui indicator de nivel și marcați-le utilizând un marker ca în figura de mai jos.



4.11 Marcarea orificiilor de fixare

Pasul 4. Gauriți în locul marcat cu ajutorul unui ciocan rotopercurtor și instalati diblurile.



PERICOL

Inainte de a guri peretele asigurati-vă că nu atingeți cabluri electrice sau tevi de apă.

a. Gauriti in pozitiile marcate anterior la o adancime de 60-65mm utilizand un ciocan rotopercutor cu varful de diametru 10mm.

b. Strangeti parcial un surub pe diblu si introduceti-l utilizand un ciocan de cauciuc.




Figura 4.12 Executarea orificiilor de fixare si introducerea diblurilor

Pasul 5. Aliniati panoul din spate cu gaurile facute, introduceti si strangeti suruburile cu o cheie dinamometrica (forta de strangere 3 Nm) cum e prezentat in figura de mai jos.




Figura 4.13 Instalarea panoului de fixare a invertorului.

4.6 Instalarea invertorului propriu-zis

Urmati pasii de mai jos:

Pasul 1. Folosind manerele de pe lateralele invertorului ridicati-l si aliniati-l cu panoul din spate deja montat.

Pasul 2. Monteaza invertorul pe acest panou aliniind orificiile de fixare.

Pasul 3. Strangeti suruburile hexagonale in ambele parti ale invertorului cu o forta de 3Nm.




Figura 4.14 Fixarea propriu-zisa a invertorului.

5 Conexiunile electrice

PERICOL

Inainte de a face orice conexiune electrica, asigurati-vă ca ambele comutatoare pentru curentul alternativ AC, respectiv curentul direct DC sunt operte. În caz contrar, riscati fatalitatea cauzata de tensiunile inalte prezente pe cablurile AC si DC.

5.1 Conectarea cablului de protectie impamantare (PGND)

5.1.1 Pregatire

Pregatiti cablul de impamantare si terminalele OT.

- Cablu de impamantare: este recomandat un cablu cu miez de cupru pentru exterior, cu sectiunea de 10mm² sau mai mult.
- Terminal OT: OT6-4. Specificatie surub: M4. Forta de strangere 1.2Nm.

OT 6~4



6-4 Parametru cheie

Seria de cod a produsului

Seria de cod a terminalului

NOTIFICARE!

O impamantare corecta a invertorului ajuta in a diminua efectele caderilor de tensiune si a imbunatatii rezistenta impotriva interferentelor electromagnetice (EMI). Conectati cablul de impamantare inainte de a conecta cablurile de curent alternativ, continuu si a celor de comunicatie.

NOTIFICARE!

Este recomandat ca impamantarea sa se execute in proximitate. Pentru un sistem format din inverteoare multiple in paralel este necesara ca impamantarea lor sa fie asigurata de puncte echipotentiale.

5.1.2 Procedura de cablare

Pasul 1. Indepartati stratul izolator de pe capatul cablului de impamantare utilizand un cleste de dezimbrare, pe o portiune putin mai lunga cu 2-3 mm decat clama terminalului OT, cum este prezentat in schema de mai jos.




Figura 5.1 Lungime dezisolata.

Pasul 2. Introduceti firele expuse ale cablului in clama terminalului OT si strangeti-le utilizand clestii hidraulici, cum este prezentat in schema de mai jos.




Figura 5.2 Prinderea in clema a cablului.

Pasul 3. Indepartati suruburile de la punctele de impamantare, cum este prezentat in schema de mai jos.




Figura 5.3 Indepartarea suruburilor de la punctele de impamantare

Pasul 4. Asigurati cablul PGND (dupa executarea pasilor 1&2) utilizand un surub de impamantare si strangeti-l utilizand o cheie tubulara (forta 1.2 Nm) cum este prezentat in schema de mai jos.




Figura 5.4 Asigurati cablul PGND

5.2 Conectarea cablului de iesire curent alternativ (AC)

5.2.1 Pregatiti cablul si terminalele AC.

a. Cablul pentru curent alternativ AC: cablul cu miez de cupru pentru exterior. Tabelul de mai jos descrie specificatiile exacte.

Destinatie cablu	Tip cablu	Suprafata sectiuni (mm ²)		Diametrul exterior al cablului (mm)
		Interval	Valoare recomandata	
Cablu AC	Nucleu multiplu exterior	8-14	10	14-20

Tabelul 5.1 Specificatiile cablului AC

b. Specificatiile recomandate pentru siguranta sunt prezентate in tabelul de mai jos.

Model invertor	Valoare recomandata
7K/8K	50A
10K	60A

Tabelul 5.2 Specificația sigurantei automate

AVERTISMENT

O siguranta suplimentara trebuie instalata pe iesirea AC a invertorului pentru a se asigura o deconectare sigura de la reteaua de electricitate.

AVERTISMENT

Nu conectati niciun dispozitiv intre terminalele de iesire AC ale invertorului si siguranta. Toate conectarile se vor face dupa acest punct de siguranta.

5.2.2 Procedura de conectare a cablurilor AC

NOTIFICARE!

Pentru siguranta personala si a operatiunii de conectare, pregatiti dinainte urmatoarele obiecte: cablu cu multi-fire si manta, terminal de sertizare si un instrument de sertizare.

Pasul 1. Indepartati o cantitate suficienta din izolatia cablului de iesire AC utilizand un cleste de dezimbrare.




Figura 5.5 Lungimea dezisolarii cablului

Pasul 2. Treceti firele expuse in zona de sertizare a terminalului OT si strangetile cu un cleste hidraulic. Izolati zona cu tub termocontractabil sau banda izolatoare PVC.




Figura 5.6 Sertizarea terminalelor OT

Pasul 3. Inserati cablul AC deja modificat prin papucii rezistenti la apa pastrand suficienta lungime pentru a le conecta electric.




Figura 5.7 Conecarea cablului AC

Pasul 4. Potriviti firele L,N si PE ale cablului AC la terminalele corespondente si strangeti-le impreuna utilizand o surubelnita cu forta de strangere 1.5Nm.




Figura 5.8 Conecarea firelor cablului AC

Pasul 5. Aliniati capacul care acopera terminalul AC si utilizand o surubelnita strangeti suruburile cu o forta de 1.2 Nm.




Figura 5.9 Blocarea capacului cablului AC

Pasul 6. Utilizand o cheie dinamometrica strangeti capacul de blocare peste cablul AC cu o forta de 5Nm.

5.3 Conectarea panourilor fotovoltaice



PERICOL

In conectarea panourilor fotovoltaice este nevoie sa se respecte urmatoarele precautii pentru a se evita socul electric.

Panourile fotovoltaice genereaza electricitate cand sunt expuse la razele solare astfel ca se poate genera un soc electric. La instalarea lor, recomandam acoperirea lor cu un material opac.

Inainte de a conecta cablurile DC de intrare, asigurati-vă ca tensiunea în zona DC este în limitele de siguranță și comutatorul DC al invertorului este oprit. În caz contrar, tensiunea înaltă va genera un soc electric.

Atunci când invertorul este legat la rețeaua electrică, nu este permisă intervenția sau menținerea la cablurile de intrare DC, cum ar fi deconectarea unui sir de panouri. Abia după ce invertorul este complet oprit se poate realiza intervenția.



AVERTISMENT

In impamantarea sirurilor de panouri fotovoltaice este necesara respectarea urmatoarelor precautii pentru a se evita izbucnirea unui incendiu.

Panourile conectate in serie trebuie sa fie cu specificatii identice.

Tensiunea maxima in gol a fiecarui sir de panouri trebuie sa fie mai mica sau egala cu limita admisibila curentului maxim in scurtcircuit

Tensiunea maxima in gol a fiecarui sir de PV trebuie sa fie mai mica sau egala cu tensiunea admisibila. Curentul maxim de scurtcircuit al fiecarui sir de PV trebuie sa fie mai mic sau egal cu curentul admisibil

Terminalele pozitiv si negativ ale panourilor trebuie sa fie conectate la terminalele pozitiv si negativ ale invertorului.

In timpul instalarii sirurilor PV si a invertorului, terminalele + si – ale panourilor nu trebuie puse in scurtcircuit

5.3.1 Pregatirea

Modul de conectare al panourilor la terminalele PV

Siruri PV	Rute MPPT
1	Conectat la oricare ruta MPPT
2	Conectat la rutele 1 & 3 MPPT
3	Conectat la rutele 1, 2 &3 MPPT

Cabul de intrare DC al panourilor si conectorii sunt pregatiti. Tabelul de mai jos prezinta specificatiile recomandate pentru cablul de cupru pentru exterior.

Destinatie cablu	Tip cablu	Suprafata sectiune (mm ²)		Diametru exterior cablu (mm)
		Interval recomandat	Interval	
Cablu DC	Cablu comun in standardul industriei (model PV1-F)	4-6	4	5-8

Tabelul 5.3 Specificatii recomandate pentru cablul de intrare DC

Conectorii sirurilor de PV: Sunt folositi conectori de intrare de curent continuu, dupa cum se vede in figura de mai jos




Figura 5.10 Ilustratie Conector pozitiv / negativ

NOTIFICARE!

Conectorii metalici pozitivi si negativi sunt livrati impreuna cu conectorii de plastic aferenti in momentul expedierii. Dupa desfacerea ambalajului, va rugam sa tineti conectorii separat pentru a evita orice confuzie.

Procedura de conectare a panourilor fotovoltaice

Pasul 1. Indepartati suficient izolatia cablurilor electrice pozitiv si negativ utilizand un cleste de dezimbrare, cum este prezentat in figura urmatoare.




Figura 5.11 Indepartarea izolatiei cablului DC (mm)

Pasul 2. Inserati partea dezisolata a cablurilor electrice pozitiv si negativ in partea de metal a terminalelor corespondente si fixati-le impreuna folosind un instrument de sertizat.




Figura 5.12 Sertizarea unui conector metalic

Pasul 3. Inserati cablurile sertizate in conectorii corespondenti negativ si pozitiv pana auziti un clic, cum prezinta figura de mai jos.




Figura 5.13 Atasarea la conectori

Pasul 4. Strangeti piulitele de blocare la conectorii pozitiv si negativ utilizand o cheie de indepartare, cum prezinta figura de mai jos.




Figura 5.14 Blocarea conectorilor

Pasul 5. Masurati tensiunea pe fiecare sir al rutelor un multimetru. Asigurati-v-a ca polaritatile cablurilor de intrare DC sunt corecte, cum este prezentat in figura de mai jos.




Figura 5.15 Masurarea tensiunii pe fiecare canal al sirului

Pasul 6. Inserati conectorii pozitiv si negativ in terminalele corespondente ale invertorului pana auziti un clic, cum se prezinta mai jos.




Figura 5.16 Conectarea la invertor

Pasul 7. Dupa conectarea sirurilor de panouri fotovoltaice, asigurati-v-a ca toti conectorii sunt blocati in pozitie, miscand putin de ei.

5.4 Conectarea cablurilor de comunicatie

5.4.1 Modalitati de comunicatie

Asigurarea comunicatiei dintre invertor si alte device-uri se poate realiza prin urmatoarele modalitati: Bluetooth, WIFI, GPRS si RS485, toate acestea sunt descrise după cum urmează:

Modul Bluetooth

Pentru a folosi aceasta modalitate porniti functia Bluetooth pe telefon, setati parametrii de functionare si monitorizati invertorul prin aplicatia mobila. Pentru detalii va rugam sa consultati manualul de utilizare al aplicatiei.

Modul WI-FI & GPRS & RS485

Pentru a folosi oricare modalitate de comunicare va rugam sa consultati tabelul pentru detalii si setari.

Modul	Descriere functionalitate
WIFI	Acest mod se implementeaza prin Cloud si modul wireless al invertorului pentru a monitoriza statusul. Pentru mai multe detalii va rugam sa consultati manualul de utilizare al aplicatiei WI-FI.
GPRS	Acest mod se implementeaza prin Cloud si modul wireless al invertorului pentru a monitoriza statusul. Pentru mai multe detalii va rugam sa consultati manualul de utilizare al aplicatiei GPRS.
RS485	Interfata RS485 monitorizeaza statusul invertorului si il incarca intr-un server Cloud. Pentru mai multe detalii va rugam sa consultati manualul de utilizare al Interfetei RS485.
Nota	Acseste accesori de comunicatie se pot achiziționa de la compania producătoare a invertorului. The baud rate supported by RS485: 9600BPS

Tabelul 5.4 Descrierea modulelor de comunicatie




Figura 5.17 Diagrama invertorului + CT

< Power Limit		< Power Limit	
Power limit function	Disable	Power limit function	CT sensor
Power limit mode	Meter on Grid	Power limit mode	On Grid
Power limit CT ratio	1000:1	Power limit CT ratio	1000:1
Maximum feed in grid power(W)	0	Maximum feed in grid power(W)	0
Digital Power Meter Type	Unknown	Digital Power Meter Type	Unknown

Figura 5.18 Setari prin intermediul aplicatiei

- Functia limitatorului de putere setat pe CT sensor
- Stabiliti pozitia unde este instalat CT-ul, pe retea sau pe sarcina.
- Setati puterea maxima ce se doreste a fi injectata in retea, daca este cazul.
- Setati raportul curentilor CT-ului.

5.5.2 Diagrama invertorului + power meter




Figure 5.19 Diagrama invertorului + Power meter

< Power Limit	< Power Limit
Power limit function Disable	Power limit function Digital Power Meter
Power limit mode Meter on Grid	Power limit mode On Grid
Power limit CT ratio 1000:1	Power limit CT ratio 1000:1
Maximum feed in grid power(W) 0	Maximum feed in grid power(W) 0
Digital Power Meter Type Unknown	Digital Power Meter Type DDSU666

Figura 5.20 Setari prin intermediul aplicatiei

- Setati Functia de limitare pe "Digital Power Meter"
- Setati tipul de "Digital Power meter"
- Stabiliti pozitia unde este instalat Meter-ul, pe retea sau pe sarcina.
- Setati puterea maxima ce se doreste a fi injectata in retea, daca este necesar.
- Ajustati valorile campului "Power limit CT ration" doar in cazul folosirii unui CT.

In momentul activarii functiei de limitare a puterii injectate in retea modulul RS485 va comunica cu meterul digital utilizand protocolul Modbus-RTU(9600 BPS, 8 data bit, 1 stop bit, no parity data format) prin adresa de comunicare 1. Asigurati-v-a ca meter-ul este setat la Modbus-RTU, 9600, 8-N-1 cu adresa 1. Pentru detalii va rugam consultati manualul de utilizare al Power meter-ului.

5.6 Verificari dupa instalare

Asigurati-v-a ca instalarea invertorului s-a facut dupa indicatiile din tabelul de mai jos.

1. Niciun obiect strain nu se afla la interiorul invertorului.
2. Toate suruburile, in special cele folosite la legaturi electrice, sunt bine stranse si fixate in locasurile corespunzatoare
3. Invertorul este instalat corect si in siguranta.
4. Cablurile de impamantare, DC, AC si cele de comunicatie sunt corect legate si in siguranta.
5. Asigurati-v-a ca nu exista circuite deschise sau scurtcircuit la nici unul din terminalele AC si DC folosind un multimetru.
6. Sectoarele care trebuie izolate de apa cum sunt terminalele AC si portul RS485 cu dopuri hidroizolante.
7. Acoperitoarele terminalor AC sunt bine stranse.
8. Terminalele inactive sunt izolate / sigilate.
9. Toate simbolurile de siguranta de pe invertor sunt intacte si complete.

Tabelul 5.5 Verificari dupa instalare

6 Operarea sistemului

6.1 Pornirea invertorului

Pasul 1. Porniti comutatorul de siguranta al AC.

Pasul 2. Daca invertorul are intrerupator de pornire, actionati-l.

Step 3. Observati statusul LED al invertorului conform cu tabelului 7.1

NOTIFICARE!

In momentul in care luminile LED indica ca invertorul functioneaza on-grid inseamna ca functioneaza in parametrii corecti. Pentru orice alta intrebare despre functionarea invertorului va rugam sa cereti suportul producatorului.

6.2 Oprirea invertorului

Pasul 1. Operati o comanda de oprire din aplicatia mobila.

Pasul 2: Inchideti comutatorul de siguranta al AC.

Pasul 3. Daca invertorul are un comutator de oprire, actionati-l.




AVERTISMENT

Chiar si dupa oprirea invertorului electricitatea si caldura reziduala ramasa poate cauza electrocutari sau arsuri grave. Mantinerea invertorului trebuie sa se efectueze la 10 minute dupa oprirea completa a invertorului.

7 Interfata utilizatorului

Interfata de comunicare a invertorului cu utilizatorul este prin lumini LED sau la unele modele, ecran LCD. Luminiile LED-urilor pot fi de 3 culori: albastru, verde si rosu. Pentru mai multe detalii consultați tabelul 7.1



NOTIFICARE!

Setarile si informatiile se pot vizualiza in aplicatia mobila. Pentru detalii, consultați manualul de utilizare al aplicatiei. Manualul aplicatiei este la dispozitie pe site-ul www.nJoy.global

English

Română

7.1 Definirea informatiilor starilor

Indicator LED	Descriere	Stare
Albastru	Repaus / stand-by	Clipeste incet
	Functionare normala	Aprins
Verde	Functionare limitata	Aprins
Rosu	Vezi mai jos	
Avertisment	Ecran LCD	Stare
Supratensiune in grid	A0 Grid OV	LED rosu clipeste incet
Cadere de tensiune in grid	A1 Grid UV	LED rosu clipeste incet
Grid absent	A2 Grid Loss	LED rosu clipeste incet
Frecventa peste limita in grid	A3 Grid OF	LED rosu clipeste incet
Frecventa sub limita in grid	A4 Grid UF	LED rosu clipeste incet
Supratensiune in panourile fotovoltaice	B0 PV OV	LED rosu clipeste rapid
Eroare rezistenta de izolatie	B1 Imp abn	LED rosu clipeste rapid
Eroare curent scurgere	B2 Lkge abn	LED rosu clipeste rapid
Eroare sistem de control al puterii	C0 Powerfail	LED rosu aprins
Eroare arc electric	C1 Arc fault	LED rosu aprins
Eroare curent continuu de polarizare	C2 OP Dc OC	LED rosu aprins
Eroare releu invertor	C3 RLY abn	LED rosu aprins
Temperatura ridicata in invertor	C5 SYS OT	LED rosu aprins
Curent rezidual HCT anomal	C6 LkgCT abn	LED rosu aprins
Eroare sistem	C7 SYS err	LED rosu aprins
Eroare ventilator	C8 FAN lock	

Legatura CC subvoltata	C9 Bus UV	LED rosu aprins
Legatura CC supravoltata	CA Bus OV	LED rosu aprins
Eroare comunicatie	CB COM err	LED rosu aprins
Versiune software incompatibila	CC FW Incomp	LED rosu aprins
Eroare EEPROM	CD EEP err	LED rosu aprins
Inconsistenta la esationare	CE Inconsis	LED rosu aprins
Circuit de amplificare anormal	CG Bst abn	LED rosu aprins
Comunicatii oprite	CN RMT OFF	

Tabelul 7.1 Definirea informatiilor starilor HMI

7.2 Ecran LCD - Rasfoirea automata si semnificatia simbolurilor

Mod	Simbol afisat	Nota
Ecranul invertorului afiseaza urmatoarele sevante in modul Repaus / Stand-by	Astris 8k Ver 01.00.00	Nume produs Versiune
	Udc 360/360V Vac 220V	Tensiune PV Tensiune AC
	Today 80kWh Etot 8000kWh	Energia astazi Energia totala
	A0 Grid OV B1 Imp abn	Avertisment

Ecranul invertorului conectat la grid afiseaza informatia urmatoare:		Timer
		Puterea de iesire Energia electrica totala furnizata la iesire
		Energie totala total ore
Ecranul invertorului conectat la grid afiseaza informatia urmatoare:		Tensiune panouri PV Sarcina PV
		Tensiune AC Sarcina AC
		Ora:minute An / luna/ ziua

Tabelul 7.2 Ecran LCD - Rasfoirea automata si semnificatia simbolurilor afisate

8 Mentenanta



AVERTISMENT

Inainte de mentenanta sau punerea in functiune a intregului sistem, va rugam sa inchideti toate terminalele invertorului si sa asteptati 10 minute dupa oprirea completa pentru a fi in siguranta.

8.1 Mantinerea periodica

Componenta de verificat	Continut de verificat	Actiune	Interval de mentinanta
Statusul iesirii invertorului	Consultati statisticele randamentului electric si monitorizati constant acest parametru	NA	Saptamanal
Curatarea invertorului	Verificati periodic si asigurativa ca radiatoarele sunt curate si nu sunt blocate de alte obiecte.	Curatati periodic radiatoarele	Anual
Starea de functionare a invertorului	Verificati ca invertorul sa nu fie avariat sau deformat. Verificati ce sunet emite invertorul in timpul functionarii. Verificati ca invertorul sa mentina o comunicatie buna	Daca sunt observate defecte, inlocuiti particile care genereaza aceste defecte.	Lunar
Conexiunile electrice ale invertorului	Verificati si asigurati cablurile AC, DC si cele de comunicatie sunt bine prinse. Asigurati prinderea corecta a cablului PGND	Daca sunt observate defecte, inlocuiti cablul sau reconectati	De 2 ori pe an

Tabelul 8.1 Mantinerea periodica

8.2 Depanare invertor

Atunci cand invertorul emite un avertisment se poate consulta tabelul de mai jos pentru cele mai comune semnale, explicatia si actiunile corespunzatoare.

Nume alarma	Cauza	Actiune recomandata
Supra tensiune in grid	Tensiunea in grid depaseste nivelul admis	<ol style="list-style-type: none">Daca alarma se declanseaza accidental atunci defectul in grid a fost temporar. Nu este necesara nicio actiune.Daca alarma se repeta contactati operatorul local al retelei electrice. Dupa obtinerea aprobarii autoritatilor, revizuiti parametrii care se refera la protectia electrica din aplicatia mobila.Daca alarma persista o perioada mai indelungata, verificati daca comutatorul AC sau terminalele sunt conectate sau daca este lipsa retea.
Sub Tensiune in grid		
Peste frecventa		
Sub frecventa		
Supra tensiune la panourile PV	Tensiunea generata de panouri este mai mare decat permite invertorul	Verificati numarul de panouri si ajustati parametrii.
Subtensiune la panourile PV	Tensiunea generata de panouri este sub limita de functionare in siguranta a invertorului	<ol style="list-style-type: none">Atunci intensitatea solară slabeste, tensiunea generata de panouri scade. Nu este necesara nicio actiune.Daca exista un scurtcircuit, remediatil. Daca rezistenta de izolatie e mai mica decat normal in conditiile de umiditate, setati protectia la rezistenta de izolatie din aplicatie.
Rezistenta izolatie anormal	Un scurtcircuit s-a produs intre sirurile de panouri si impamantare. Panourile sunt instalat intr-un mediu umed sau cu umezeala prelungita.	<ol style="list-style-type: none">Verificati rezistenta la izolatie fata de impamantare a sirurilor de panouriDaca rezistenta de izolatie e mai mica decat normal in conditiile de umiditate, setati protectia la rezistenta de izolatie din aplicatie

Curent rezidual anormal	Rezistenta de izolatie fata de impamantare pe intrare e scazuta, lucru care produce curent rezidual	<p>1. Daca alarma porneste accidental, e posibil ca circuitul exterior sa aibe o scurgere accidentalala. Invertorul va reveni la functionare normala imediat dupa ce se va remedia defectiunea</p> <p>2. Daca alarma porneste repetat sau dureaza mult timp, verificati rezistenta de izolatie fata de impamantare a sirurilor de panouri</p>
Functionare atipica la panourile fotovoltaice	Sirul de panouri a fost ecranat o perioada lunga de timp Panourile se deterioreaza.	<ol style="list-style-type: none"> Verificati daca sirul de panouri este shielded. In cazul in care sirul de panouri este ecranata, verificati daca panourile nu mai dau randament si se deterioreaza.
Sirul de panouri conectat invers	Cablurile de la sirul de panouri a fost conectat invers ca polaritate	Verificati daca cablurile sirurilor de panouri sunt conectate corect. In caz contrar, corectati conectarea cablurilor conform cu manualu
BUS Under Voltage	Dezechilibru intern anormal in modulul de control al energiei. Se activeaza la schimbarea brusca a parametrilor de functionare a sirurilor de panouri sau a retelei	<ol style="list-style-type: none"> Daca alarma se declanseaza ocazional, invertorul isi reia functionarea normala automat, dupa repararea defectului initial. Daca alarma se declanseaza in mod repetat, contactati unitatea de unde ati achizitionat echipamentul pentru suport tehnic.
BUS Over Voltage		
Invert Module Fault		
BOOST Fault		
Eroare EEPROM	Componenta EEPROM defecta	Inlocuiti placa de monitorizare
Nu se genereaza curent si alarma cu iluminare galbena este activa	Communications outage	Daca modemul sau alt dispozitiv de colectare date e folosit, resetati-l. Daca in continuare nu functioneaza, contactati furnizorul

Monitorizarea raporteaza tensiune 0 la iesire	Siguranta care protejeaza iesirea este arsa / sarit	Daca siguranta DC este afectata contactati suport tehnic. Daca nu e afectata, reporniti. Daca tot nu functioneaza, contactati suport tehnic.
Invertor deconectat de la retea	1. Reteaua electrica are probleme 2. Siguranta DC arsa	1. Asteptati sa se remedieze problemele retelei electrice 2. Reporniti intrerupatorul sigurantei DC si daca se defecteaza din nou, contactati suportul tehnic.
Detectie arc electric	Descarcari electrice	1. Verificati conexiunile echipamentului, inclusiv integritatea firelor, fixarea clemelor si papucilor 2. Dupa eliminarea defectiunilor, opriti alimentarea cu curent (continuu si alternativ) si reporniti invertorul sau apasati AFD Reset in aplicatie pentru a elimina eroarea

Tabelul 8.2 Depanare invertor

NOTIFICARE!

Daca alarmele nu se pot stinge in urma actiunilor recomandate, contactati suportul tehnic.

8.3 Dezinstalarea invertorului

Pentru a indeparta invertorul va rugam sa urmati procedura de mai jos:

Pasul 1. Deconectati toate cablurile atasate la invertor, inclusiv cele de comunicatie, intrare DC, iesire AC si cablul PGND.

NOTIFICARE!

La deconectarea conectorului intrarii DC, inserati cheia de departare la conectorul baioneta, apasati cheia in jos si scoateti cu grijă conectorul.

Pasul 2. Scoateti invertorul de pe panoul de instalare.

Pasul 3. Indepartati panoul de pe perete.



AVERTISMENT

Inainte de a scoate conectorul DC de intrare, verificati cu grijă si asigurati-vă ca intrerupatorul DC este oprit pentru a evita vatajari corporale si defecte ale invertorului.

9

Colectarea invertorului pentru reciclare

In momentul in care perioada de viata a invertorului a expirat, NU ARUNCATI invertorul impreuna cu gunoiul menajer, ci respectati procedurile locale de colectare a deseurilor de acest tip.



Dezafectarea echipamentelor electrice și electronice vechi

(Se aplică pentru țările membre ale Uniunii Europene și pentru alte țări europene cu sisteme de colectare separată).

Acest simbol aplicat pe produs sau pe ambalajul acestuia indică faptul că acest produs nu trebuie tratat ca pe un deșeu menajer.

Ei trebuie predat punctelor de reciclare a echipamentelor electrice și electronice.

Asigurându-vă că acest produs este dezafectat în mod corect, veți ajuta la prevenirea posibilelor consecințe negative asupra mediului și a sănătății umane, care ar fi putut surveni dacă produsul ar fi fost dezafectat în mod necorespunzător.

Reciclarea materialelor vă ajută la conservarea resurselor naturale.



Memo

English

România

